

# TOTO


- TOTO ASIA OCEANIA PTE. LTD.** 10, Eunos Road 8, #12-07, Singapore Post Centre. Singapore 408600.  
Phone : +65-6744-6955 Fax : +65-6841-0819 <http://asia.toto.com/>
- TOTO ASIA OCEANIA PTE. LTD.** Middle East Branch LOB19-1701-1702, Jebel Ali Free Zone, P.O. box 261804, Dubai U.A.E.  
Phone : +971-4-886-5983 Fax : +971-4-886-5986 <http://asia.toto.com/>
- TOTO ASIA OCEANIA PTE. LTD.** Manila Representative Office. Unit 1010, 10th Floor Rufino Building, Ayala Avenue cor.V.A. Rufina Street, Makati City,1226 Philippines.  
Phone : +63-2-887-6643 Fax : +63-2-887-4084 <http://asia.toto.com/>
- TOTO Manufacturing (Thailand) LTD.** 598 Q HOUSE Ploenjit BLD., G Floor, Ploenchit Rd., Lumpini, Pathumwan, Bangkok 10330, Thailand  
Phone : +66-2-650-9925 Fax : +66-2-650-9923 <http://www.toto.co.th/>
- TOTO INDIA INDUSTRIES PVT. LTD** 101, Kamla Executive Park, Opp. Vazir Glass Works, Off. Andheri Kurla Road, Andheri (East), Mumbai 400 059, India.  
Phone : +91-22-4022-3717 / 3718 Fax : +91-22-4022-3719 <http://asia.toto.com/>
- TOTO VIETNAM Co., Ltd.** R. 810, Daeha Business Centre, 360 Kim Ma St., Ba Dinh Dist., Ha Noi City  
Phone : +84-4-37714354 Fax : +84-4-37714355 <http://toto.com.vn/>
- TOTO (H.K.)LTD.** RM.1101, 11/F No.3 Lockhart Rd. Wanchai, Hong Kong  
Phone : 852-2861-3177 / Fax : 852-2861-3563

# TOTO

## WASHLET

## washlet

TCF6632\*\*\*  
TCF6631\*\*\*  
TCF6630\*\*\*



- You are advised to record the following information to allow quick service.

Date of purchase :	Name of shop :
Date : year month day	Tel : (     )

2014.10.21  
D08891

- Thank you for your recent purchase of the product. Please read the enclosed information to ensure the safe use of your product.
- Be sure to read this Instruction Manual before using your product and keep it in a safe place for future reference.

# What functions are available on your product?

Check your model name and write a check mark in this field as needed.

Product name (Model)		WASHLET			Ref. Page	
Part No.		TCF6632***	TCF6631***	TCF6630***		
Your Model						
Functions						
Basic Functions	Cleansing	Rear cleansing	●	●	●	13
		Rear soft cleansing	●	●	●	
		Front cleansing	●	●	●	
	Changing the washing method	Wand position adjustment	●	●	●	
		Water pressure adjustment	●	●	●	
		Oscillating cleansing	●	●	●	
	Drying	Warm air drying	●	●	●	
Changing the temperature	Temperature adjustment	●	●	●	16, 17	
Sanitary Functions	Removing odors	Deodorizer	●	●	●	14, 15
	Bowl pre-cleaning	Pre-mist	●	●	●	
Convenient Functions	Heating the toilet seat	Heated seat	●	●	●	—
	Saving energy	Energy saver	●	●	●	18, 19
Maintenance	Main Unit	One-touch removal	●	●	●	24
	Removable toilet lid		●	●	●	25
	Wand cleaning		●	●	●	26

Product name, Part No.



The self-cleaning functions operate automatically. (See pages 14 and 15 for details.)

### As you sit

- A mist is sprayed in the toilet bowl.
- The deodorizer operates.

## Table of Contents

Safety Precautions .....	4	Introduction
Operational Precautions.....	9	
Parts Names .....	10	
Preparation.....	12	

Basic Operations .....	13	Operation
Automatic Functions.....	14	
DEODORIZER, PRE-MIST		
Temperature Adjustment.....	16	
Energy Saver Feature .....	18	



Main unit.....	22	Maintenance
Deodorizing Filter .....	23	
Gap between the Main Unit and the Toilet Bowl .....	24	
Gap between the Main Unit and the Toilet Lid .....	25	
Wand .....	26	
Wand cleaning		
Water Filter Drain Valve.....	27	

Changing Settings .....	28	Reference
What to Do?.....	32	
● Freeze Damage Prevention ...	32	
● Long Periods of Disuse.....	33	
Troubleshooting .....	34	
Specifications .....	38	
Warranty .....	39	



# Safety Precautions

These precautions are important for safe usage. Be sure to follow them and use the product correctly.

## Symbols and Meanings


	<b>WARNING</b>	May result in death or serious injury.
	<b>CAUTION</b>	May result in injury or property damage.

The following symbols are used to indicate important safety instructions for the use of the product.

Symbol	Meaning
	This symbol indicates a prohibited use of the product.
	This symbol is used to indicate a required step in the use of this product.

- This product is classified as Class 1 Equipment and must be grounded.
- Install this equipment where the electrical outlet is accessible.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Use the new hose set included with this equipment. Do not reuse an old hose set.

## WARNING

	<b>Do not touch the power plug or connection of power cord with wet hands.</b>
	• Doing so may cause electrical shock.
	<b>Do not get any water or cleaning solution on the main unit or power plug or connection of power cord.</b>
	• Doing so may cause fire, electrical shock, heat or short circuit. • Doing so may cause the product to crack resulting in injury or water damage.
	<b>Never disassemble, repair or alter.</b>
	• Doing so may cause fire, electrical shock, heat or short circuit.
	<b>Do not install the product on moving vehicles such as wheeled vehicles or boats.</b>
	• Doing so may cause fire, electric shock, short circuit or malfunction. • The toilet seat, toilet lid, main unit or other parts may come loose and fall off, resulting in injury.

## WARNING

### Do not use the Washlet if a malfunction occurs.

- In the following cases, switch the breaker on the distribution board to OFF and close the shutoff valve.
- Close the water shutoff valve to stop water supply.

Possible malfunctions:

- Water is leaking from a pipe or the main unit.
- The product is cracked or broken.
- The product makes a strange noise or emits a strange odor.
- The product emits smoke.
- The product is abnormally hot.
- The toilet seat cushion is out of place.

- Continued use after malfunction could cause a fire, electric shock, heat, short circuit, injury or water damage.

### Only use tap water or potable well water (underground water).

#### Do not use seawater.

- Doing so may cause irritation to the skin and malfunction.

### Do not touch the power plug or connection of power cord during thunderstorms.

- Doing so may cause electrical shock.

### Do not allow the water supply hose to touch the power plug, outlet or connection of power cord.

- Doing so may cause condensation resulting in a fire, electrical shock, heat or a short.

### Do not do anything that may damage the power cord, power plug.

Do not strike, yank, twist, excessively bend, damage, alter, or heat the electrical cords. Also, do not place anything heavy on, bind or pinch the electrical cords.

- Using a damaged electrical cord may result in a fire, electrical shock, heat or short.

### Do not use a loose or faulty electrical outlet.

- Doing so may cause fire or short circuit.

### Do not use any outlet or wiring equipment beyond its specified rating.

- Plugging too many plugs into the same outlet, for example using outlet splitters, can cause fire due to heat.

### Do not use any power supply other than the one specified.

**AC 220-240V, 50Hz/60Hz**

- Doing so may cause fire or excessive heat.

### Do not stick a finger or anything else into the warm air outlet.

Do not place anything on the warm air outlet or drape clothes over it.

- Doing so may cause burns, electrical shock or malfunction.

### Keep cigarettes and other open flames away from the product.

- Failure to do so may cause fire.

# Safety Precautions (Continued)

## WARNING

### Beware of irritation or burn

- Improper use of the toilet seat may cause irritation or burn.  
When sitting for a long time on the toilet seat, switch the toilet seat temperature adjustment to "OFF". When any of the following persons use a heated seat or warm air drying, someone should switch the toilet seat temperature adjustment to "OFF" and switch the drying air temperature to "Low".
  - Young children, the aged and other users unable to set the temperature appropriately themselves
  - The ill, physically disabled and others who do not have freedom of movement.
  - Those using any medicines that cause drowsiness (sleeping or cold medicine), those who have been drinking heavily, anyone severely fatigued and anyone else liable to fall asleep.

**This is an electrical product. Do not install it anywhere water is likely to get on the product or anywhere with humidity high enough that water is likely to form on the surface of this product. When using the product in a bathroom, install a fan or ventilation port and ensure good air flow through the bathroom.**

- Failure to do so may cause fire or electrical shock.

### Always connect the Washlet to the cold water supply.

- Connecting to hot water supply may result in burns and equipment damage.

### Check that an appropriate ground is installed.

- If the ground is not installed, if there is a breakdown or electrical current leak, the lack of a ground could cause electrical shock.  
For the ground, use copper wire with a ground resistance of 100  $\Omega$  max. and a diameter of 1.6 mm min.  
\* If there is no ground installed, ask the contractor who did the installation to install the ground.

### Make sure that a properly grounded (3 prong) outlet has been installed.

- Failure to install a grounded outlet could cause electrical shock in the event of a malfunction or short circuit.

### Insert the power plug securely into the outlet.

- Failure to do so may cause fire, heat or short circuit.

### Check that the power plug is waterproofed with silicone rubber.

- A power plug that is not water-proofed may cause fire and electrical shock.  
\* If the power plug is not water-proofed, ask the contractor who did the installation to water-proof it.

### To unplug, hold the plug, not the cord.

Do not unplug by pulling the cord.

- Pulling on the cord may cause damage and result in fire or heat.

**If the electric cord is damaged, avoid danger by having the manufacturer's repair department or equivalent specialist replace it.**

### Always turn off the breaker on the distribution board before cleaning, maintenance or examination.

- Doing so may cause electrical shock or malfunction.  
Except when using "Wand cleaning"

## WARNING



**Preliminary studies in females suggest that overuse of continuous spraying can increase the possibility of vaginal mucosa drying and potential reduction in desirable microbial organisms.**

**Although these studies have not been validated, please consult your healthcare provider for concerns regarding whether these circumstances may apply to you. More importantly, if you are an individual suffering from any immune deficiency as a result of disease, chemotherapy, or other medical condition compromising the immune system you should consult your healthcare provider before use of this product.**

**Always switch the breaker on the distribution board to OFF before removing the main unit.**

- Failure to do so may cause fire or electrical shock.

## CAUTION



**Do not use the product if the main unit is unstable.**

- Doing so may cause the main unit to come loose and fall, resulting in injury.

**If the product is damaged, do not touch the damaged section.**

- Doing so may cause electrical shock or injury. Replace it immediately.

**Do not apply strong force, mechanical shock, step on or stand on the toilet seat, toilet lid or main unit. Also do not place any heavy object on the toilet seat, toilet lid or main unit.**

- Doing so may cause cracking or cause the main unit to come loose and fall, resulting in injury.
- Doing so may damage the product and cause injury or water damage.

**Do not lift up this product by the toilet seat or lid.**

**Do not raise the toilet seat or lid while objects are resting on top of the toilet.**

- Doing so may cause the main unit to come loose and fall, resulting in injury.

**When cleaning or maintaining the plastic parts (main unit etc.) or the water supply hose, use a kitchen cleaner diluted with water. Do not use any of the following. Toilet cleaner, household cleaner, benzene, paint thinner, powdered cleanser or nylon scrubbing pads.**

- These items may damage or crack the plastic and cause injury or malfunction.
- These items could damage the water supply hose and cause a water leak.

# Safety Precautions (Continued)

## ⚠ CAUTION



**To prevent a sudden water leak, do not remove the water filter drain valve when the shutoff valve is open.**

- Doing so will cause water to spurt out.  
(Refer to Page 27 for instructions on cleaning the water filter drain valve.)

**Do not fold or crush the water supply hose; do not damage by cutting with a sharp object.**

- Doing so may cause water leaks.

**Do not install the base plate, which is not attached.**

- Doing so could cause a fire or damage.

**If a water leak should occur, always close the shutoff valve.**

**When the ambient temperature is likely to drop to 0°C or lower, prevent damage to the pipes and hoses due to freezing.**

- Frozen water pipes could cause the main unit and the pipes to break, resulting in a water leak.
- Regulate the room temperature to prevent the pipes and hoses from freezing during cold months.
- Drain the water.

**When not using the Washlet for a long time, close the shutoff valve, drain the water from the main unit and water supply hose, and then turn off the breaker on the distribution board.**

When using the product again, allow the product to refill with water first.

- Otherwise, the water in the tank might become contaminated and cause skin inflammation or other problems. (Refer to Page 33 for instructions on replenishing the water.)
- Leaving the power on may cause fire or heat.



**When installing the water filter drain valve, make sure that it is securely tightened in its proper position.**

- Failure to securely tighten it may cause a water leaks.

**Push the main unit securely on to the base plate.**

After pushing the main unit until a click sound is heard, pull it slightly toward you to make sure that the product does not detach.


- Failure to do so could cause the main unit to come loose and fall resulting in injury.

# Operational Precautions

## ■ For prevention of malfunctions

### < About the seat switch >

- When you sit on the toilet seat, the seat switch turns ON, enabling you to use various features.  
(A click sound is heard when the seat switch is ACTIVATED.)



- Sit back on the toilet seat.
  - The seat switch will not turn on unless you sit on the seat properly.



### Note

- When a child uses the Washlet, the seat switch may not be ACTIVATED by their light body weight.
- Since the toilet seat is designed to move up and down, a clearance is provided between the toilet seat cushion and the toilet bowl.

## ■ For prevention of damage

- Wipe plastic areas such as the main unit and remote control with a soft, wet cloth.
- Do not lean against the toilet lid.




## ■ Problem Prevention

- Switch the breaker on the distribution board to OFF if there is a risk of lightning.
- A toilet seat cover or a toilet lid cover cannot be used. (The seat switch may not function properly.)




- Do not urinate on the main unit, toilet seat or wand. (Doing so may cause pink or brown stains or a malfunction.)
- Do not apply strong forces to the control panel.
- When using a toilet cleaner to clean the toilet, wash it off within 3 minutes and leave the toilet seat and toilet lid open. Wipe off any cleaner that remains on the toilet bowl. (If vapor from a toilet bowl cleaner enters the main unit, it may cause a malfunction.)
- Do not expose to direct sunlight. (Doing so may cause changes in color, irregular heated seat temperature, the control panel malfunction or Washlet malfunction due to the change in temperature.)
- Use radios, etc. away from the Washlet. (The Washlet could cause interference with the radio signal.)
- If you use a booster seat for infants or a soft highchair, remove it after use. (Keeping it installed may prevent some of the functions from being used.)
- Do not place anything on the toilet seat and lid, and do not press them with hands. Failure to do so may turn on the seat switch, causing the floor to get wet if buttons on the control panel are touched and warm water comes out from the wand. (The seat switch may turn on if force is applied to the toilet seat or lid.)

# Parts Names




## Left side of main unit

Water filter drain valve (Page 27)



Water drain plug (Page 33)


## Right side of main unit




Deodorizer outlet

Main unit removal button (Page.24)


Deodorizing filter (Page.23)




Toilet seat cushions



TCF6632\*\*\*



TCF6630\*\*\*




The toilet seat and lid shape varies by model.

# Preparation

## Using the Product for the First Time


### 1. Turn on the power

- Switch the breaker on the distribution board to ON.
  - The wand extends and then retracts.
- Check that the POWER LED on the main display is lit up.



### 2. Open the shutoff valve

- Fully open the shutoff valve.



# Basic Operations

## Cleansing

**[REAR]** Cleanses your rear.

**[SOFT REAR]** Washes your rear with mild water pressure.


**[FRONT]** Serves as a bidet for ladies.

**[OSCILLATING]** When you press this button again during use, the wand moves back and forth to wash your rear thoroughly.

## Drying

**[DRYER]** Dries your rear.

## Stopping **[STOP]**



● Functions that operate when a button is pressed during "REAR", "SOFT REAR" or "FRONT" cleansing.

### **[PRESSURE]**

- You can adjust the water pressure as desired to 5 different levels.
- The PRESSURE LEDs lights up when you sit on the toilet seat.

Note

- Sitting back on the toilet seat makes it easier to adjust the wand position and to reduce splashing.

### **[POSITION]**

- You can adjust the washing position as desired to 5 different points.
- The washing position returns to the standard position (3rd point) when you stand up from the toilet seat.

### For your information

- Water may sometimes come out from around the wand when it expands in the warm water tank, but this is normal.
- As the warm water tank of hot-water system is used, the temperature of warm water may become lower if it is continuously consumed.

# Automatic Functions

## Cleaning Features

As you approach



As you sit



As you stand up\*



### Note

### Changing settings

### If dirt adheres...

■ If dirt adheres to the wand during use, you can extend the wand to clean it.

- Cleaning the wand (Page 26)

## DEODORIZER



Starts the deodorizer

Deodorizer stops  
→It stops after about 2 minutes

- DEODORIZER ON/OFF (Page 30)

A mist is sprayed inside the toilet bowl to make it more difficult for dirt to adhere

## PRE-MIST



A mist is sprayed inside the toilet bowl.

- The pre-mist will not spray for about 90 seconds after you stand up from the toilet seat.

- PRE-MIST ON/OFF (Page 30)



\* To sanitize the toilet bowl every time it is used, water remaining in the wand is drained after you stand up from the toilet seat.



# Temperature Adjustment

## Warm Water / Toilet Seat / Drying

Three different temperature levels (high / medium / low) and "OFF" setting can be made.



## Adjusting the temperature


1 Select a temperature button you want to set from



• The current temperature level appears.

2 Press the button selected in step 1 repeatedly until a desired temperature level lights up.

The setting changes each time the button is pressed



The "DRYER" cannot be turned "OFF".

<Setting complete>

Note

- If the button is not pressed for about 10 seconds, the temperature adjustment LED will go off, but the setting will be retained. If the temperature adjustment LED goes out before the setting is completed, start all over again at step 1.
- When the toilet seat does not get warm, or when the warm water is not warm enough, even after temperature adjustment. →Is the energy saver set to "ON"? (Page 20)

## To turn the warm water temperature and toilet seat temperature "OFF" \*The "DRYER" cannot be turned "OFF".


1 Select a temperature button you want to turn "OFF" from



• The current temperature level appears.

2 Press the button selected in step 1 repeatedly until the temperature level is set to "OFF".

The setting changes each time the button is pressed






<Setting complete>

# Energy Saver Feature

You can save energy by turning the toilet seat heater to a low temperature (or turning the heater "OFF") during periods when the toilet will be used infrequently.

- It takes about 10 days for the product to determine the periods when it is used relatively less frequently.

Type	Situation	When energy saver is set	When energy saver is in operation		AM		PM				
		Main Display		Toilet seat heater	Warm water heater	0	6	8	5	9	0
<b>ENERGY SAVER</b>	<p><b>You want the Washlet to save energy automatically</b></p> <p>The Washlet detects time periods with infrequent use and lowers the toilet seat temperature automatically. Furthermore, it automatically turns off the toilet seat and warm water heater during time periods when the toilet is never used.</p>	<p>Lit (Green) — ENERGY SAVER</p> <ul style="list-style-type: none"> <li>SEAT</li> <li>WATER</li> <li>POWER</li> </ul> 	<p>Time period with infrequent use</p> <p>Lit (Orange)</p> <ul style="list-style-type: none"> <li>ENERGY SAVER</li> <li>SEAT</li> <li>WATER</li> <li>OFF — POWER</li> </ul> 	Low	Set temperature <sup>*1</sup>	0	6	8	5	9	0
		<p>When energy saver is not set</p> <p>OFF — ENERGY SAVER</p> <ul style="list-style-type: none"> <li>SEAT</li> <li>WATER</li> <li>POWER</li> </ul>	<p>Time period the toilet is never used</p> <p>Lit (Orange)</p> <ul style="list-style-type: none"> <li>ENERGY SAVER</li> <li>SEAT</li> <li>WATER</li> <li>OFF — POWER</li> </ul> 	OFF	OFF	Low temperature <sup>*2</sup>	Set temperature <sup>*1</sup>	0	6	8	5

Example) Time period with infrequent use (from 9:00PM to 6:00AM): Low  
Time period the toilet is never used (8:00AM to 5:00PM): OFF

Operation

**Note**

- Even if the toilet seat heater is being activated (with the toilet seat heater set to "Low" or "OFF," or with the warm water heater set to "OFF"), the toilet seat will be temporarily heated when you sit on it. (To reach the setting temperature, the toilet seat and warm water take about 15 minutes and 10 minutes, respectively.)

\*1 The temperature set on Page 16.


\*2 The time period when the toilet seat heater is set to a "low temperature" by the energy saver. The warm water heater is "Set temperature".

\*3 The time period when the toilet seat heater and warm water heater are "OFF".

To set energy saver Page 20 - 21

# Energy Saver Feature

## How to set



Energy-saver setting button

# ENERGY SAVER

**1** Press .

The setting changes each time the button is pressed


**ON**

Lit (Green)

**OFF**

OFF

Operation



The ENERGY SAVER LED will be lit if the energy saver feature is working.  
 ENERGY SAVER : Lit (Orange)

# Maintenance

## ⚠ WARNING

**!** Always turn off the breaker on the distribution board before cleaning, maintenance or examination.  
(Failure to do so may cause electric shock or malfunction, resulting in a breakdown.)

**\* For safety, turn off the breaker on the distribution board before cleaning or maintenance.**




**Do not use a dry cloth or toilet paper on plastic parts.**  
(May cause damage.)



\* Except when using "Wand cleaning".

## Main Unit (Perform daily)




Soft cloth soaked in water

- Toilet paper
- Dry cloth
- Nylon scrubbing pads (May cause damage.)

- 1 Switch the breaker on the distribution board to OFF.
- 2 Wipe with a soft cloth that has been soaked in water and wrung-out thoroughly.

### ■ For heavy dirt

- Wipe with a soft cloth soaked in diluted, neutral kitchen detergent, and then wipe with a soft cloth soaked in water.



• Neutral kitchen detergent


- Paint thinner
- Benzene
- Powdered cleanser

- 3 Switch the breaker on the distribution board to ON.

- The POWER LED lights up.

### Attention!


- **The Washlet is an electric appliance.**  
Be careful not to let water seep inside or leave detergent in the gap between the main unit and toilet bowl.  
(May damage plastic parts or cause a malfunction.)
- **When using a toilet cleaner to clean the toilet, wash it off within 3 minutes and leave the toilet seat and toilet lid open.**
  - Wipe off any cleaner that remains on the toilet bowl. (If vapor from a toilet bowl cleaner enters the main unit, it may cause a malfunction.)
- **Do not push or pull the covers around the wand with undue force.**  
(May cause damage or malfunction.)



## Deodorizing filter (Perform monthly)

<If you notice odors>


- 1 Switch the breaker on the distribution board to OFF.
- 2 Remove the deodorizing filter.
  - Hold the knob and pull outward.
  - Do not pull with undue force. (May cause damage or malfunctions)



- 3 Clean with a tool such as a toothbrush.
  - When washing with water, dry off all water before mounting.



- 4 Mount the deodorizing filter.
  - Push firmly until a click sound is heard.



- 5 Switch the breaker on the distribution board to ON.
  - The POWER LED lights up.

# Maintenance

## Gap between the Main Unit and Toilet Bowl (Perform monthly)

You can remove the main unit to clean the top of the toilet bowl and the bottom of the main unit.



Soft cloth soaked in water




Toilet paper, etc. (May cause damage.)

- 1 Switch the breaker on the distribution board to OFF.

If the breaker on the distribution board is not turned off, the unit may malfunction or cause a failure or electric shock.


- 2 Remove the main unit.
  - Do not pull the unit with undue force (because the water supply hose and power cord are attached).



Pull the main unit toward you while pressing the button.

- 3 Clean the gap.
  - Wipe with a soft cloth soaked in a diluted, neutral kitchen detergent. Then, wipe it with a soft cloth soaked in water so that no detergent remains.

- 4 Mount the main unit.



**CAUTION**  
 Push the main unit firmly onto the base plate until a click sound is heard.

After mounting, check that the main unit does not detach even when pulled.

- 5 Switch the breaker on the distribution board to ON.
  - The POWER LED lights up.

## Gap between the Main Unit and the Toilet Lid (Perform monthly)

The toilet lid can be removed for thorough cleaning.



Soft cloth soaked in water



Toilet paper, etc. (May cause damage.)

- 1 Switch the breaker on the distribution board to OFF.

- 2 Remove the toilet lid.
  - A: Pull the left side outward.
  - B: Disconnect the hinge from the recess and pull up.
  - C: Disconnect the right side.

- 3 Wipe with a soft cloth that has been soaked in water and wrung-out thoroughly.

- 4 Reinstall the toilet lid.
  - D: Join the pin and the hinge on the right side.


Slightly tilt the toilet lid to the front.

  - A: While pulling out the left side,
  - E: Mount by joining the hinge with the recess.

\* Be careful not to pinch your fingers.

- 5 Open and close the toilet lid to check the mounting, and then mount the main unit.

- 6 Switch the breaker on the distribution board to ON.
  - The POWER LED lights up.



# Maintenance

## Wand (Perform monthly)

<Wand cleaning> If you notice dirt




Soft cloth soaked in water





Toilet paper, etc.  
(May cause damage.)

- 1 Press
  - The wand extends and water sprays out for cleaning.
  - The wand automatically retracts after about 5 minutes.

- 2 Wipe with a soft, wet cloth.
  - Do not pull, push or press the wand with excessive force. (May cause damage or malfunction.)



- 3 Press
  - The wand retracts.



Water filter drain valve


## Water filter drain valve (Perform once every 6 months)

<If you think the water pressure has weakened>

- 1 Close the shutoff valve.
  - The water supply stops.

### CAUTION


- Do not remove the water filter drain valve while the shutoff valve is open. (Otherwise, water may leak out)



- 2 Press to extend the wand, and then press again to return the wand. (Release the pressure from the water supply pipe.)


- 3 Switch the breaker on the distribution board to OFF.

- 4 Remove the water filter drain valve.
  - Loosen with a flat-head screwdriver and then pull.



- 5 Clean with a tool such as a toothbrush.
  - Also, remove any dust from inside the hole of the water filter drain valve.

- 6 Reinstall the water filter drain valve.
  - Insert the water filter drain valve and tighten it securely with a flat-head screwdriver.




- 7 Switch the breaker on the distribution board to ON.
  - The POWER LED lights up.

- 8 Open the shutoff valve.

# Changing Settings


## Setting List

To change the settings, check that all LEDs on the control panel are flashing!



● Press about 10 seconds or longer STOP

All LEDs on the control panel flash.



Settings cannot be changed unless all LEDs flash


Setting Types			Available Settings*	Setting Ref. Page
AUTO FUNCTIONS	CLEANING	PRE-MIST	ON/OFF	Page 30
		DEODORIZER	ON/OFF	

\*The black text is the initial setting.

### Note

- If you do not press a next button within about 60 seconds after the LED flashes, the flashing LED will be disabled. If you fail to complete the setting, redo from the beginning.

# Changing Settings



## CLEANING

**1** Press until all LEDs on the control panel start flashing (about 10 seconds)

Set whether or not to spray mist automatically after sitting on the toilet seat  
**PRE-MIST**

**2** Press and at the same time. The setting changes each time the button is pressed

ON	OFF
<input type="checkbox"/> ENERGY SAVER	<input type="checkbox"/> ENERGY SAVER
<input checked="" type="checkbox"/> SEAT	<input checked="" type="checkbox"/> SEAT
<input checked="" type="checkbox"/> WATER	<input checked="" type="checkbox"/> WATER
Flickering (Orange) <input checked="" type="checkbox"/> POWER	OFF <input type="checkbox"/> POWER

Set whether or not to deodorize automatically after sitting on the toilet seat  
**DEODORIZER**

**2** Press . The setting changes each time the button is pressed

ON	OFF
<input type="checkbox"/> ENERGY SAVER	<input type="checkbox"/> ENERGY SAVER
<input checked="" type="checkbox"/> SEAT	<input checked="" type="checkbox"/> SEAT
<input checked="" type="checkbox"/> WATER	<input checked="" type="checkbox"/> WATER
Flickering (Green) <input checked="" type="checkbox"/> POWER	OFF <input type="checkbox"/> POWER

**3** Press <Settings complete>



# What to Do?

## Freeze Damage Prevention

When the ambient temperature is likely to drop to 0°C or lower, take measures to prevent freezing.

### Attention!

- When the ambient temperature is likely to drop to 0°C or lower, do not use the energy saver feature. (May damage the product.)
- Warm the bathroom or take measures against freezing so that the ambient temperature does not drop below 0°C.

### Freeze damage prevention

#### 1 Close the shutoff valve.

- The water supply stops.

**CAUTION**


Do not remove the water filter drain valve while the shutoff valve is open. (Otherwise, water may leak out)

#### 2 Drain the water from the toilet tank.


- Turn the flush handle of the toilet tank to the full flush side.
- Turn the lever until water flow stops.

#### 3 Drain the pipe.

- (1) Press to extend the wand, and then press again to return the wand. (Release the pressure from the water supply pipe.)
- (2) Switch the breaker on the distribution board to OFF.
- (3) Remove the water filter drain valve.




#### (4) Drain the water from the water supply hose.




#### (5) After draining the water, install the water filter drain valve.

- Insert the water filter drain valve and use a flat-head screwdriver to tighten it securely.



#### (6) Switch the breaker on the distribution board to ON.

#### 4 Check that the POWER LED on the main display is lit up.



#### 5 Set the water and toilet seat temperature to "High". (Page 16)

- (To maintain the temperature.)
- When finished, close the toilet seat and toilet lid.

#### ■ To use the Washlet again

- The water needs to be resupplied. (Page 33)

## Long Periods of Disuse

If the toilet is in a location you will not visit for a long time, drain the water.

(The water in the tank may become contaminated and cause skin irritation or other problems.)


### How to drain the water

#### 1 Drain the water from the toilet tank. (Step 1 2 on Page 32)


#### 2 Drain the pipe. (Step 3 (1) to (5) on Page 32)

#### 3 Remove the water drain plug.

- The water comes out from near the wand for about 90 seconds.



#### 4 Reinstall the water drain plug.



#### ■ If water may get frozen

- Add antifreeze solution in the water in the bowl to prevent freezing. (The antifreeze solution should not be flushed out. Collect it before using the toilet and dispose of it.)

#### ■ To use the Washlet again

- The water needs to be resupplied. (See below)

### Resupplying the Water (After draining)


#### 1 Open the shutoff valve.

- Check that water is not leaking from a pipe or the main unit.

#### 2 Switch the breaker on the distribution board to ON.

#### 3 Discharge water from the wand.

- (1) Pressing down the right side of the toilet seat,
- (2) Press [REAR] on the remote control for about two minutes to discharge water from the wand. (It takes about one minute before water comes out. Catch the water in a paper cup or other receptacle.)




#### ■ If the remaining water has frozen and no water comes out

- Heat the inside of the bathroom, and warm the water supply hose and shutoff valve using a cloth soaked in warm water.

# Troubleshooting

First, try the actions described on pages 34 to 37. If the problem persists, consult the installer, seller or the contact listed on the back cover of this manual.



## Please check first


Is the **POWER LED** lit?

■ Is the **POWER LED** flickering?

→ The main unit is not mounted properly. Mount the main unit again. (Page 24)

■ Is the breaker on the distribution board turned on?

→ Check whether there is a power outage or the breaker has turned "OFF".



Is the **ENERGY SAVER** LED lit?

■ While the LED is lit, energy saver (Page 18) is in operation, so the toilet seat temperature may be reduced or the heater may be turned off.

## Rear and Rear soft, front cleansing, wand

Trouble	Please check	Ref. Page
<b>The wand (or cleansing water) does not come out</b>	● When the temperature is low, it takes time for the wand to come out after the control panel button is pressed because the water must be warmed up first.	-
	● Did you sit on the toilet continuously for 2 hours or longer? (If so, operation is stopped for safety purposes.) → Stand up from the seat and then use again.	-
	● If the water supply pressure drops significantly, for example if water is used elsewhere or if there is a water failure, the function may stop for safety. → Switch the breaker on the distribution board to OFF and wait about 10 seconds before inserting it again. If the same symptom reappears → There may be a malfunction. Consult with the contact listed on the back cover of this manual.	-
	● The seat switch may have difficulty detecting some sitting postures. → Sit back on the toilet seat.	9
	● Are you using a toilet seat cover, a toilet lid cover or a seat for infants? → Remove any covers. When using a seat for infants or a soft highchair, remove after each use.	9
<b>The wand extends but the cleansing water does not come out /The cleansing water pressure is weak</b>	● Has a water failure occurred? → Press the "STOP" button and wait until water service is restored.	-
	● Is the shutoff valve closed?	12
	● Is the water filter drain valve clogged with foreign matter? → Clean the filter.	27
	● Is the water pressure set to a low level?	13
<b>The cleansing water is cold</b>	● Is the water drain plug loosened? → Tighten the water drain plug securely.	33
	● Is the water temperature set to "OFF" or a low level? ● When the temperature of the water supply or the bathroom is low, the water temperature may be low when first sprayed.	16 -
<b>Stops in the middle of use</b>	● Rear, rear soft and front cleansing stop automatically after 5 minutes of continuous use. ● Does the seat switch have difficulty detecting? → Sit back on the toilet seat. If you get up slightly from the seat, or sit forward on the seat, the seating switch may temporarily stop detecting your presence.	- 9
<b>Water comes out unexpectedly from the wand</b>	● Water may sometimes come out from around the wand when it expands in the warm water tank.	-

# Troubleshooting

## Warm air drying

Trouble	Please check	Ref. Page
The dryer temperature is low	<ul style="list-style-type: none"> <li>● Is the control panel preset temperature set to a low level?</li> </ul>	16
Stops in the middle of use	<ul style="list-style-type: none"> <li>● The feature stops automatically after 10 minutes of continuous use.</li> <li>● Does the seat switch have difficulty detecting?                             <ul style="list-style-type: none"> <li>→ Sit back on the toilet seat. If you get up slightly from the seat, or sit forward on the seat, the seating switch may temporarily stop detecting your presence.</li> </ul> </li> </ul>	9

## Toilet Seat and Toilet Lid

Trouble	Please check	Ref. Page
The toilet seat is cold	<ul style="list-style-type: none"> <li>● Is the toilet seat temperature set to "OFF" or a low level?</li> </ul>	16
	<ul style="list-style-type: none"> <li>● Is the ENERGY SAVER LED (orange) lit?                             <ul style="list-style-type: none"> <li>• When the SEAT LED (green) is also lit.</li> <li>→ The toilet seat temperature has been lowered to save energy. When you sit, the toilet seat is temporarily heated.</li> </ul> </li> <li>• When the SEAT LED is OFF.</li> <li>→ Energy saver is operating and has turned off the toilet seat heater. When you sit on the seat, the toilet seat heater is turned on temporarily and the seat is warmed in about 15 minutes.</li> </ul>	18
	<ul style="list-style-type: none"> <li>● Have you been seated for a long time?                             <ul style="list-style-type: none"> <li>• After about 20 minutes of sitting, the temperature starts going down, and after about 1 hour, the toilet seat heater is turned "OFF".</li> <li>→ Stand up from the seat and then use again.</li> </ul> </li> </ul>	-
	<ul style="list-style-type: none"> <li>● Did you put anything on the toilet seat or the toilet lid?                             <ul style="list-style-type: none"> <li>→ Remove the object from the toilet seat or the toilet lid.</li> </ul> </li> </ul>	-
	<ul style="list-style-type: none"> <li>● The seat switch may have difficulty detecting some sitting postures.                             <ul style="list-style-type: none"> <li>→ Sit back on the toilet seat.</li> </ul> </li> </ul>	9
	<ul style="list-style-type: none"> <li>● Is a toilet lid or seat cover installed?                             <ul style="list-style-type: none"> <li>→ Remove any covers.</li> </ul> </li> </ul>	9


## Energy Saver

Trouble	Please check	Ref. Page
The energy saver feature is not working	<ul style="list-style-type: none"> <li>● Because the function takes several days learning the usage conditions before starting energy saver, the amount of energy saving may be low, depending on the frequency of use.                             <ul style="list-style-type: none"> <li>→ Check the energy saver feature.</li> </ul> </li> </ul>	18

## Deodorizer

Trouble	Please check	Ref. Page
The deodorizer seems to be not working	<ul style="list-style-type: none"> <li>● Is "DEODORIZER" set to "OFF"?                             <ul style="list-style-type: none"> <li>→ Set to "ON".</li> </ul> </li> </ul>	30
	<ul style="list-style-type: none"> <li>● Even after sitting down, you do not hear operation sounds.                             <ul style="list-style-type: none"> <li>→ Sit back on the toilet seat.</li> </ul> </li> <li>● If you hear an operation sound when you sit on the toilet seat.                             <ul style="list-style-type: none"> <li>→ Clean the deodorizing filter.</li> </ul> </li> </ul>	9 23
A strange odor is emitted	<ul style="list-style-type: none"> <li>● Are you using an air freshener or deodorizer that you purchased separately?                             <ul style="list-style-type: none"> <li>• Doing so may reduce the effectiveness of the Washlet deodorizer or cause strange odors.</li> <li>→ Remove the air freshener or deodorizer.</li> </ul> </li> </ul>	-

## Others

Trouble	Please check	Ref. Page
Water is leaking from the plumbing connections	<ul style="list-style-type: none"> <li>● If any nuts in a connection are loose, firmly tighten them with a tool such as a monkey wrench.</li> </ul> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Do not use tools on the water supply hose connection. Tighten it by hand.</p>  </div> <ul style="list-style-type: none"> <li>→ If the water leak does not stop, close the shutoff valve and seek repair.</li> </ul>	-
The main unit is unstable	<ul style="list-style-type: none"> <li>● There is clearance between the toilet seat cushion and the toilet bowl for activating the seat switch. When you sit on the toilet seat, the toilet seat subsides slightly to activate the seat switch.</li> <li>● Are the bolts that anchor the main unit loose?                             <ul style="list-style-type: none"> <li>→ Remove the main unit and then firmly tighten the base plate bolts.</li> </ul> </li> </ul>	9 24
The main unit makes a sound	<p>&lt;Only when sitting on the toilet seat.&gt;</p> <ul style="list-style-type: none"> <li>● You hear operation sounds for preparing the pre-mist or spraying mist in the toilet bowl.                             <ul style="list-style-type: none"> <li>→ You can turn them "OFF".</li> </ul> </li> </ul> <p>&lt;When moving away from the toilet bowl after use&gt;</p> <ul style="list-style-type: none"> <li>● You may hear the sound of the remaining water being drained.</li> </ul>	14 30 -
You feel air in the toilet bowl when sitting on the toilet seat	<ul style="list-style-type: none"> <li>● A mist is sprayed inside the toilet bowl to make it more difficult for dirt to adhere when sitting on the toilet seat. You may feel air when a mist is sprayed.                             <ul style="list-style-type: none"> <li>→ You can turn it "OFF".</li> </ul> </li> </ul>	14 30

# Specifications

Item		TCF6632***	TCF6631***	TCF6630***	
Rated power supply		AC 220-240 V 50 Hz / 60 Hz			
Rated power consumption		262-307 W			
Type of water heater		Tank type			
Power cord length		1.2 m (For Singapore, 5.0m)			
Water protection level		IPX4			
Functions	Cleansing	Rear cleansing	Approx. 0.27 to 0.43 L/min. <at 0.20 MPa water pressure>		
		Spray volume	Rear soft cleansing	Approx. 0.27 to 0.43 L/min. <at 0.20 MPa water pressure>	
			Front cleansing	Approx. 0.29 to 0.43 L/min. <at 0.20 MPa water pressure>	
		Water temperature	Adjustable temperature range: OFF, about 35°C to 40°C		
		Toilet tank capacity	0.64 L		
		Heater capacity	195-232 W		
		Safety device	Temperature fuse, overheat shutoff switch (bimetal automatic return type), anti-idling float switch		
	Backflow prevention device	Vacuum breaker			
	Warm air dryer	Warm air temperature <sup>1</sup>	Adjustable temperature range : about 30°C to 55°C		
		Airflow volume	Approx. 0.27 m <sup>3</sup> /min		
		Heater capacity	185-220 W		
		Safety device	Temperature fuse		
	Heated seat	Surface temperature	Adjustable temperature range: OFF, about 28°C to 36°C <About 26°C when energy saver is in operation>		
		Heater capacity	45-54 W		
		Safety device	Temperature fuse		
	Deodorizer	Method	O <sub>2</sub> deodorization		
		Airflow volume	Approx. 0.16 m <sup>3</sup> /min		
Power consumption		Approx. 5.3 W			
Water supply pressure		Minimum required water pressure: 0.05 MPa (dynamic, 10 L/m or more), Maximum required water pressure: 0.75 MPa (static)			
Water supply temperature		0°C to 35°C			
Working ambient temperature		0°C to 40°C			
Dimensions		W 480mm D 523mm H 188mm	W 480mm D 531mm H 188mm	W 480mm D 480mm H 188mm	
Weight		About 5 kg			

\* Temperature around the warm air outlet measured by TOTO.

# Limited Warranty

## LIMITED ONE YEAR WARRANTY

- TOTO warrants its products to be free from manufacturing defects under normal use and service for a period of one (1) year from the date of purchase. This warranty is extended only to the ORIGINAL PURCHASER.
- TOTO's obligations under this warranty are limited to repair or replacement, at TOTO's option, of products or parts found to be defective, provided that such products were properly installed and used in accordance with this OWNER'S MANUAL. TOTO reserves the right to make such inspections as may be necessary to determine the cause of the defect. TOTO will not charge for labor or parts in connection with warranty repairs or replacements. **TOTO is not responsible for the cost of removal, return and/or reinstallation of products.**
- This warranty does not apply to the following items:
  - Damage or loss sustained in a natural calamity such as fire, earthquake, flood, thunder, electrical storm, etc.
  - Damage or loss resulting from any unreasonable use, misuse, abuse, negligence, or improper maintenance of the product.
  - Damage or loss resulting from removal, improper repair, or modification of the product.
  - Damage or loss resulting from sediments or foreign matter contained in a water system.
  - Damage or loss resulting from the quality of water in the region where the product is used.
  - Damage or loss resulting from improper installation or from installation of a unit in a harsh and/or hazardous environment.
  - Damage or loss resulting from electrical surges or lightning strikes or other acts which are not the fault of TOTO or which the product is not specified to tolerate.
  - Damage or loss resulting from normal and customary wear and tear, such as gloss reduction, scratching or fading over time due to use, cleaning practices or water or atmospheric conditions.
- This warranty gives you specific legal rights. You may have other rights which vary from country to country.
- To obtain warranty repair service under this warranty, you must take the product or deliver it prepaid to a TOTO service facility, together with a letter stating the problem, or contact a TOTO distributor or product service contractor, or directly to TOTO sales office. If, because of the size of the product or nature of the defect, the product can not be returned to TOTO, receipt by TOTO of written notice of the defect shall constitute delivery. In such case, TOTO may choose to repair the product at the purchaser's location or pay to transport the product to a service facility.

WARNING! TOTO shall not be responsible or liable for any failure of, or damage to, this Product caused by either chloramines in the treatment of public water supply or cleaners containing chlorine (calcium hypochlorite). NOTE: The use of a high concentrate chlorine or chlorine related product's can seriously damage the fittings. This damage can cause leakage and serious property damage.

THIS WRITTEN WARRANTY IS THE ONLY WARRANTY MADE BY TOTO. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY SHALL BE THE EXCLUSIVE REMEDY AVAILABLE TO THE PURCHASER. TOTO SHALL NOT BE RESPONSIBLE FOR LOSS OF USE OF THE PRODUCT OR FOR OTHER INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGE OR EXPENSES INCURRED BY PURCHASER, OR FOR LABOR OR OTHER COSTS DUE TO INSTALLATION OR REMOVAL, OR COSTS OF REPAIRS BY OTHERS, OR FOR ANY OTHER EXPENSE NOT SPECIFICALLY STATED ABOVE. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR USE, ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGE, SO THE ABOVE LIMITATION AND EXCLUSION MAY NOT APPLY TO YOU.